
UFB3 FenerBalat

WHE-PAGER PHASE 2: DEVELOPMENT OF ANALYTICAL SEISMIC VULNERABILITY FUNCTIONS		
Author		
Author: Date:	1-Sep-09	
Structure type (describe as broadly as possible):	UFB3	
Geographic or other limitations:	FenerBalat	
Seegrapine of outer miniations.	1 onorbaid.	Add rows as desired
	Choice of pushover curve parameters	
	Units Parameter	
Pushover X-axis:	Sd(m) Deltar Choose spectral displacement (Sd); or Roof displacement (I	
Pushover Y-axis:	Sa(g) Sa Choose spectra acceleration (Sa); or base shear (V). State Small-amplitude damping ratio, fraction of critical	s units.
Elastic damping ratio: 1st mode participation factor:	PFfR; generally 1.3 to 1.5; same as (effective height)/(total r	roof hoight)
Effective mass coefficient:	0.92 alpha1; generally 0.7 to 0.8	Tool neight)
Building weight:	Weight of the W State units	
How were these values & pushover points derived?	Using FaMIVE data set	
	se Mechanisms and Seismic Vulnerability of Historic Masonry Buildings' Earthquake Spectr	tra: 19: 479-509 Add rows as desired
Ref. D Figure D., Speranza E., Deminton of Cona	Pushover Curve for this structure type	Add Tows as desired
	See Figures 1-4 for sample pushover curves	
Pushover curve control poi		
	A Control point for plotting purpose	ses
	B 0.01 0.1323 E.g., yield point?	
	C 0.04599117 0.189 E.g., ultimate point?	
	D 0.15 0 E.g., beginning of lower plateau	u?
	E Add rows as desired	
Haran haved avalance avanage at 00 and of 400 hi	Optional: upper and lower-bound range of pushover curves for this st	
Author's meaning of "upper bound":	ildings of this type would have pushover curve inside the area bounded between this curve a	and the Y-axis?
How were these values & pushover points derived?		
		Add rows as desired
	See Figures 1-4 for sample pushover curves	
	Optional upper-bound pushover curve	
Pushover curve control poi		
	A 0 0 Control point for plotting purpose	ses
	E.g., yield point?	
	E.g., ultimate point?	
	D E.g., beginning of lower plateau	u?
	E Add rows as desired	
Lower-bound pushover curve, e.g., 99 out of 100 bu	ildings of this type would have pushover curve inside the area bounded between this curve	and the X-axis?
Author's meaning of "lower bound":		
How were these values & pushover points derived?		
	Son Figures 1.4 for cample purpover survey	Add rows as desired
	See Figures 1-4 for sample pushover curves Optional lower-bound pushover curve	
Pushover curve control poi		
i usilovei edive edililei pei	A 0 0 Control point for plotting purposi	SAS
	B E.g., yield point?	
	C E.g., ultimate point?	
	D E.g., beginning of lower plateau	u?
	Add rows as desired	
Other requested parameters		
D14		structural damage, i.e., drift with 50% chance that the structural component of the building cannot be economically repaire
B14	0.059 logarithmic standard deviation of drift associated with complete structural of the median value of drift (in same units as pushover X-axis) associated with	
Sdc L15	indoor fatality rate given collapse. Many contributors may be unable to pro	
PC	mean fraction of building area collapsed, given complete structural damage	
kshort	If HAZUS-style damping preferred, and author can judge, this is the degrad	
kmed	If HAZUS-style damping preferred, and author can judge, this is the degrad	
klong	If HAZUS-style damping preferred, and author can judge, this is the degrad	
Explain how these values were arrived at, providing		
		Add rows as desired

UFB3 FenerBalat



Spectral displ., Sd, m

UFB3 FenerBalat




Figure 1: Force-displacement capacity boundary with all idealized segments present




Figure 2: Force-displacement capacity boundary without strain hardening segment (e.g. buckling braced frame)

